


100g双胶纸 风琴折 尺寸177x77mm

正


Conference Speakerphone

User Manual


What's in the box




Speakerphone x 1



Protective Bag x 1




USB Adapter X 1



User Manual X 1


Overview



Speaker Mute Microphone
VOL- VOL+
Line in / out


Easy Set-Up

①




(Bottom)


②



③



1. Connect the USB Speaker phone to conference host by USB. (Compatible to any host OS of Windows/Android/iOS).
2. Choose "USB speaker phone" as audio input&output in the setting of conference host or conference software.

 Mute/un-mute microphone

When microphone light becomes red, it's in the mute state.

When microphone light becomes blue, it's in working state.


- Speaker volume down
+ Speaker volume up

反


会议麦克风

用户手册


包装清单



会议麦克风 x 1



收纳包 x 1



转接头 x 1



用户手册 x 1

产品概览



扬声器 静音键 麦克风
音量- 音量+
音频输入/输出


快速安装指南

①




(底部)


②



③



1. 将会议全向麦克风USB线插入电脑USB端口，会议全向麦克风在连接电脑时将自动开启（兼容Windows、Android、IOS操作系统）。
2. 在电话软件或者电脑设置中选择会议全向麦克风作为音频设备。

 对麦克风设定静音/解除静音

麦克风指示灯红色即为静音状态。
麦克风指示灯为蓝灯即为工作状态。

- 扬声器音量减小
+ 扬声器音量增加